

## Material release

### CompactFloor® EXPERT

Attention: Lay CompactFloor® EXPERT according to installation instructions. Leave adhesive to cure completely and keep surface free of dust. Process recommended products in accordance with manufacturer's instructions.

<b>Parquet</b>	8 mm mosaic block / herringbone	8 mm solid english bond straight / ladder pattern	10 mm solid parquet lamparquet	2- or 3-layer ready-made parquet short format less than 100 cm	2- or 3-layer ready-made parquet plank / country style single plank	22 mm strip parquet and solid parquet	22 mm on-edge lamel parquet	Laminate Manufacturer release for full-surface bonding required
<b>Adhesive</b>	PARFIX ECO PLUS or PARFIX ELASTIC							
<b>Primer</b>	not necessary							
<b>Decoupling</b>	not necessary					Bostik Renofleece	Bostik Renofleece	not necessary
<b>if required</b> <b>Primer on compensation</b>	not necessary							
<b>Compensation</b>	<p>NIBOPLAN FA 600 or ARDALAN FLEX</p> <p>When using said compensation compound, one of the following primer should be used under the compensation: NIBOGRUND G 16 (1:1 diluted with water) or ARDAGRIP CLASSIC</p>							

<b>Tiles / Natural stone</b>	<b>Ceramic tiles / Porcelain stoneware</b> Tile size: max. 120 x 120 cm Minimum thickness: 9 mm Technical joint width: min. 3 mm	<b>Natural stone</b> Tile size: max. 120 x 120 cm Minimum thickness: 15 mm Technical joint width: min. 3 mm
<b>Joint mortar</b> Test jointing recommended	ARDACOLOR CLASSIC or ARDACOLOR PREMIUM	
<b>Adhesive</b>	ARDAFLEX TILE ADHESIVE or FLOORFLEX XXL	ARDAFLEX MARMOR FAST oder ARDAFLEX S2 PREMIUM
<b>Primer</b>	A primer is only necessary when using ARDAFLEX TILE ADHESIVE: NIBOGRUND G 16 (1:1 diluted with water) or ARDAGRIP CLASSIC	
<b>Decoupling</b>	not necessary	Bostik insulation panel 4 mm
<b>if required</b> <b>Sealing in damp rooms</b>	ARDATEC FLEXDICHT	
<b>Primer on compensation</b>	not necessary	
<b>Compensation</b>	<p>NIBOPLAN FA 600 or ARDALAN FLEX</p> <p>When using said compensation compound, one of the following primer should be used under the compensation: NIBOGRUND G 16 (1:1 diluted with water) or ARDAGRIP CLASSIC</p>	

<b>Textile / Elastic floor coverings</b>	Textile coverings	PVC / CV coverings design coverings	Needle punched flooring
<b>Adhesive</b>	NIBOFLOOR S800		POWER TEX
<b>Primer</b>	not permitted		
<b>if required</b> <b>Primer on compensation</b>	not necessary		
<b>Compensation</b>	<p>NIBOPLAN FA 600 or ARDALAN FLEX</p> <p>When using said compensation compound, one of the following primer should be used under the compensation: NIBOGRUND G 16 (1:1 diluted with water) or ARDAGRIP CLASSIC</p>		